



Secure up to four extrication tools in minimal space with this easy-to-use rotating platform.

Adjustable mounting brackets accommodate most brands of cutter, spreader, and combination tool - both hydraulic and electric.

Simply press down on the yellow paddle to disengage the lock and rotate the turntable to access the tool you need. Turntable safely locks into place after each 90-degree rotation for quick and safe tool retrieval.

To replace one of the four standard tool brackets with a ram bracket (see below right), order Model QM-MEH-1-R.

Reference Manual 3095PM16



MODEL	DESCRIPTION	WT./@ IN LBS.	PRICE LIST PAGE NO.
QM-MEH-1	Multiple extrication tool holder	54.0	22
QM-MEH-1-R	Multiple extrication tool holder w/ram option	54.0	22
QM-MEH-2-R	Multiple extrication tool holder w/2 ram option	54.0	22
QM-MEH	Multiple extrication tool holder - tower & table only	48.0	22

QUIC-MOUNT™ Strut Brackets

Secure 3” wide box and cylinder struts with these heavy-duty powder-coated cast aluminum brackets. Flexible, UV-stabilized draw latches hold struts firmly in place.

For struts less than 3” wide, we recommend the use of a spacer to achieve an optimum fit.

Low profile brackets are ideal for areas with restricted space requirements.

Cup mount holds 2-3/4” and 3-1/2” diameter cylindrical struts.

Sold each.



Model VM-SB



Model VM-SB-C



Model LPSB (sold per each)

MODEL	DESCRIPTION	WT./@ IN LBS.	PRICE LIST PAGE NO.
VM-SB	Variable mount strut bracket	.8	20
VM-SB-S	Variable mount strut bracket with spacer	.9	20
VM-SB-C	Variable mount cup strut bracket	2.0	20
LPSB	Low profile strut bracket	.7	20
LPSB-S	Low profile strut bracket with spacer	.8	20



.5” Spacer